

Unit Display: English V

# CarTech<sup>®</sup> O1

Email Datasheet

Print Now

Add to My Materials

Identification

NS Number	
T31501	
ISI Number	-
Type O1	

#### **Type Analysis**

Single figures are nominal except where noted.

Carbon	0.90 %	Manganese	1.20 %
Chromium	0.50 %	Vanadium	0.20 %
Tungsten	0.50 %	Iron	Balance

**General Information** 

#### Description

CarTech 01 is a manganese-chromium-tungsten, nondeforming, oil hardening general purpose tool and die steel which is safe to harden, even in intricate sections.

It is produced from billets that are 100% acid disc inspected and ultrasonic tested, insuring sound metal in the finished bars.

### Applications

CarTech 01 has found applications in the following types of tools and dies:

Blanking dies Forming dies Lamination dies Molding dies Trimming dies Broaches Collets Stamps Master tools Spindles Master taps Thread gauges

Properties		
Physical Properties		
Specific Gravity		
	7.87	
Density		
	0.2830 lb/in <sup>3</sup>	
Mean CTE		
100 to 500°F	6.00 x 10 <sup>-6</sup> in/in/°F	
100 to 800°F	7.10 x 10 <sup>-6</sup> in/in/°F	
100 to 1000°F	7.80 x 10 <sup>-6</sup> in/in/°F	
100 to 1200°F	8.00 x 10 <sup>-6</sup> in/in/°F	

# Coefficient of thermal expansion

From 100°F to	38°C to	10"/°F	10"/°C
500	260	6.0	10.8
800	427	7.1	12.8
1000	538	7.8	14.0
1200	649	8.0	14.4

---

31.0 x 10<sup>3</sup> ksi







# Percent Elongation in 2" (50.8 mm) and Reduction in Area

Tensile and Yield Strength



# Un-notched Izod Impact



**Heat Treatment** 

#### Decarburization

01 has no special tendency to decarburize. If the hardening instructions are carefully followed, tools should be hard right out to the surface.

#### Normalizing

Forgings can be normalized by heating uniformly to 1600°F (871°C), then cooling in still air. This procedure is suitable for large forgings.

#### Annealing

01 should be packed in a suitable container using a neutral packing compound or placed in a controlled atmosphere furnace.

Heat uniformly to  $1400/1450^{\circ}F$  (760/788°C), then cool very slowly in the furnace at a rate of not more than  $20^{\circ}F$  (11.1°C) per hour until the furnace is black. The furnace may then be turned off and allowed to cool naturally. This will produce a maximum hardness of Brinell 217.

#### Hardening

01 may be hardened from temperatures between 1450/1500°F (788/816°C). Endothermic atmospheres should be held to dew point limits between 45/55°F (7/18°C). This wide hardening range makes it possible to fit into many heat treating schedules during the average day. This broad a hardening range supersedes all other references to 01 hardening temperatures previously published.

Without preheating, place the tool right in the hot furnace and let it heat naturally until its color uniformly matches the color of the thermocouple in the furnace. Soak an additional 5 minutes per inch of thickness, then quench in oil. The temperature of the tool should be brought right down to the temperature of the oil in the quench.

The basket in the quenching tank serves as a good place to store hardened tools while waiting to be tempered.

01 is an easy tool to harden. Simply heat it, soak it, then quench it. This procedure saves time and trouble, is the safest procedure and yields better tools.

#### Deformation (Size Change) in Hardening

The accompanying hyperlink entitled "Size Change in Hardening" shows typical length changes of 01 when it has been properly hardened and tempered. Note that the length change information is presented in inches per inch of original length.

When properly hardened, 01 will expand slightly, but will return close to its original size upon tempering.

The data show the average size change in this steel per inch of length. That is, a piece 1" long will expand approximately 0.002" (0.0051 mm) when hardened, but when tempered between 300/400°F (149/204°C) will return within 0.001" (0.0025 mm) or its original size.



#### Stress Relieving

To relieve machining stresses for greater accuracy in hardening, first rough machine, then heat to a temperature of 1200/1250°F (649/677°C), hold at heat for a minimum of 1 hour, then cool slowly. After cooling, the part or parts may be finish machined.

#### Tempering

Temper 01 immediately to the desired hardness level. The minimum tempering time is 1 hour at temperature. Be sure to allow sufficient time to allow the material to reach the proper temperature. Sections over 2 inches thick should be tempered one hour per inch.

The effects of different tempering temperatures on the hardness of 01 are shown in the hyperlink entitled "Effect of Tempering Temperature on Hardness".

Tempering Temperature		Rockwell C Hardness
٩F	°C	Rockwell C Hardness
As Hardened		63/65
200	93	63/65
300	149	63/65
350	177	62/64
400	204	60/63
450	232	60/62
500	260	58/60
600	316	55/57
700	371	52/54
800	427	48/50
900	482	44/47
1000	538	40/44

## Effect of Tempering Temperature on Hardness of 01 Oil quenched from 1475°F (802°C), tempered 1 hour at indicated temperature

#### Forging

Heat slowly and uniformly to 1800/1900°F (982/1038°C), then proceed to forge. Do not work below 1500°F (816°C). Cool forgings slowly in ashes, lime or in the furnace.

### Machinability

The machinability of 01 may be rated between 65/75% of a 1% carbon water hardening tool steel or approximately 50/60% of B1112.

Approximate turning speeds of 90/105 surface feet per minute (SFPM) (0.46/0.53 m/s) are suggested when using high speed cutting tools.

	Other Information
Applicable Specifications	
• ASTM A681	
Forms Manufactured	
Bar-Rounds	
Technical Articles	

• A New Guide for Selecting Ferrous Alloys, Tungsten Carbides and Ceramics for Tooling

#### **Disclaimer:**

The information and data presented herein are typical or average values and are not a guarantee of maximum or minimum values. Applications specifically suggested for material described herein are made solely for the purpose of illustration to enable the reader to make his/her own evaluation and are not intended as warranties, either express or implied, of fitness for these or other purposes. There is no representation that the recipient of this literature will receive updated editions as they become available.

Unless otherwise specified, registered trademarks are property of CRS Holdings Inc., a subsidiary of Carpenter Technology Corporation. Copyright 2019 CRS Holdings Inc. All rights reserved.

Edition Date: 05/01/1986

Contact our U.S. Sales Office or one of our International Sales Offices for more information.